


pH Titration curves

pH/Titration curves

#Chemistry

General

Many indicators are weak acids and partially dissociate in aqueous solutions



The un-ionised form (HIn) is a different colour to the anionic form.


Apply Le Chatelier's Principle to predict any colour change

In Acid:

- Increase of $[\text{H}^+]$
 - equilibrium moves to the left to give red undissociated form In Alkali:
 - Increase of $[\text{OH}^-]$
 - OH^- ions remove H^+ ions to form water; $\text{H}^+_{(aq)} + \text{OH}^-_{(aq)} \rightleftharpoons \text{H}_2\text{O}_{(l)}$
 - equilibrium moves to the right to produce a blue colour
-

Acid Base Indicators

- Must have an easily observable colour change.
- Must change immediately in the required pH range over the addition of 'half' a drop of reagent (the solution in your burette). To be useful, an indicator must change over the "vertical" section of the curve where there is a large change in pH for the addition of a very small volume of alkali. The indicator used depends on the pH changes around the end point - the indicator must change during the 'vertical' portion of the curve.





In the example, the only suitable indicator is Phenolphthalein.

There are four types of acid-base titration; each has a characteristic curve.


1. Strong Acid HCl vs. Strong Base NaOH
2. Weak Acid CH_3COOH vs weak base NH_3
3. Strong Acid HCl vs weak base NH_3
4. Weak acid CH_3COOH vs weak base NH_3

In the following examples, alkali(0.1M) is added to 25cm³ of acid (0.1M).

End points need not be "neutral" due to salt hydrolysis (you don't have to know about this)

strong acid (HCl) v. strong base (NaOH)**strong acid (HCl) v. weak base (NH₃)**




strong acid (HCl) v. strong base (NaOH)



Any of the indicators listed will be suitable - they all change in the 'vertical' portion

Other pH curves - acid v. carbonate

Sodium carbonate reacts with hydrochloric acid in two steps...



There are two sharp pH changes

First rapid pH change around pH = 8.5
due to the formation of NaHCO_3 .

Can be detected using **phenolphthalein**

Second rapid pH change around pH = 4
due to the formation of acidic CO_2 .

Can be detected using **methyl orange**.

